

SPECIFICATION FOR SPARE PARTS LIST



SPA-01

AIR HOSE ADAPTOR
M5x0.45, 1/4"x19



SPA-02

TIRE ADAPTOR



SPA-03

AIR HOSE ADAPTOR M5x0.45



SPA-04

1/8" AIR HOSE ADAPTOR



SPA-05

ADAPTOR M5x0.45-1/8"



SPA-06

ADAPTOR 1/8"x1/8"



SPA-07

ADAPTOR 1/8"x1/4"



SPA-08

1/8" QUICK RELEASE
ADAPTOR




SPA-09

QUICK RELEASE
ADAPTOR M5x0.45




SPA-10

PRESSURE REGULATOR
1/8"-1/8"




SPB-01

WRENCH



SPB-02

WRENCH



SPB-03

WRENCH